KARTA INFORMACYJNA PRODUKTU

Lokalizator GPS 4G z odcięciem paliwa StealthTrack™ Control (J16)

Monitoring samochodu, historia tras i zdalne zabezpieczenie - montaż przewodowy

Kategoria	Samochodowy lokalizator GPS/GNSS z funkcją sterowania przekaźnikiem
Łączność	4G LTE (B1/B2/B3/B4/B5/B7/B8/B28/B66) oraz 2G GSM; moduł SIMCOM A7670SA
Pozycjonowanie	GPS + BDS (BeiDou), AGPS i LBS; dokładność orientacyjnie 10–30 m w otwartej przestrzeni
Zasilanie	Z instalacji pojazdu, DC 9–90 V; nie wymaga regularnego ładowania
Funkcja odcięcia	Blokada uruchomienia pojazdu przez kompatybilny przekaźnik; wymaga montażu
Karta SIM	Wymagana aktywna karta SIM z transmisją danych; wariant zestawu według oferty
Wymiary i waga	80 × 35 × 17 mm; ok. 49 g
Gwarancja	**2 lata** zgodnie z ofertą sprzedawcy

Opis produktu

StealthTrack™ Control to kompaktowy lokalizator GPS 4G przeznaczony do dyskretnego montażu w instalacji pojazdu. Po aktywacji karty SIM i konfiguracji aplikacji pozwala sprawdzać pozycję samochodu. Z kompatybilnym przekaźnikiem może dodatkowo blokować możliwość uruchomienia silnika.

Najważniejsze zalety

- Podgląd lokalizacji auta na mapie w czasie rzeczywistym.
- Historia tras, postoje i Geo-Fence - zależnie od używanej aplikacji.
- Alerty dotyczące ruchu, wibracji i zdarzeń - zależnie od konfiguracji.
- Stałe zasilanie samochodowe i dyskretny montaż bez regularnego ładowania.
- Możliwość blokady uruchomienia po podłączeniu odpowiedniego przekaźnika.

Karta SIM i działanie online

Do przesyłania pozycji potrzebna jest aktywna karta SIM z pakietem internetu oraz zasięg zgodnej sieci 4G/2G. Dostępność karty, przekaźnika i usług platformy zależy od wybranego wariantu sprzedaży.

Ważne: montaż i bezpieczne użycie blokady

Instalację elektryczną i przekaźnik powinien podłączyć specjalista. Funkcja blokady służy do zabezpieczenia **zatrzymanego pojazdu**; nie należy jej używać do wyłączania silnika podczas jazdy.

Jak to działa

1. Przygotuj kartę SIM
Włóż aktywną kartę SIM z transmisją danych i skonfiguruj usługę lokalizacyjną.
2. Zamontuj lokalizator
Zleć podłączenie przewodów do instalacji pojazdu; opcjonalnie podłącz przekaźnik.
3. Połącz z aplikacją
Dodaj identyfikator urządzenia i korzystaj z mapy, historii oraz dostępnych alertów.

PRODUCT INFORMATION SHEET

StealthTrack™ Control (J16) 4G Car GPS Tracker with Fuel Cut-Off

Live vehicle tracking, trip history and remote immobilisation - wired installation

Category	Vehicle GPS/GNSS tracker with relay-control capability
Connectivity	4G LTE (B1/B2/B3/B4/B5/B7/B8/B28/B66) and 2G GSM; SIMCOM A7670SA module
Positioning	GPS + BDS (BeiDou), AGPS and LBS; indicative accuracy 10–30 m under open sky
Power supply	Wired to the vehicle electrical system, DC 9–90 V; no routine charging
Cut-off function	Vehicle start inhibition via compatible relay; professional installation required
SIM card	Active data-enabled SIM card required; bundle depends on sales option
Size and weight	80 × 35 × 17 mm; approx. 49 g
Warranty	**2 years** according to the seller's offer

Product description

StealthTrack™ Control is a compact 4G GPS tracker designed for discreet, wired installation in a vehicle. After inserting an active SIM card and setting up the app, it can display the vehicle location remotely. When fitted with a compatible relay, it can also prevent the engine from being started.

Key benefits

- Real-time vehicle location displayed on a map.
- Trip history, stops and Geo-Fence - depending on the tracking app.
- Motion, vibration and event notifications - depending on configuration.
- Continuous vehicle power supply with no routine device recharging.
- Optional start-blocking function with a correctly installed compatible relay.

SIM card and online operation

Location updates require an active data-enabled SIM card and coverage from a compatible 4G/2G network. SIM card inclusion, relay availability and platform services depend on the chosen sales option.

Important: installation and safe use of cut-off

Vehicle wiring and the relay should be installed by a qualified specialist. The blocking function is intended for a **stationary vehicle** and must not be used to stop an engine while driving.

How it works

1. Prepare the SIM card
Insert an active data-enabled SIM card and configure the tracking service.
2. Install the tracker
Have the device wired to the vehicle; connect a compatible relay if included.
3. Connect the mobile app
Add the device ID and access location, trip history and available alerts.